

Work Order ID 126404

November-06-14 11:44:00 AM

126404

Page 1

Item ID: D206-781-023L08 Accept *N900040100* Setup Start *NS1*
 Revision ID: Stop *NS2*
 Item Name: Floor Protector - Passenger Cabin Clear
 Start Date: 11/06/14 Start Qty: 5.00 *5* Cust Item ID:
 Required Date: 11/14/14 Req'd Qty: 5.00 *5* Customer:
 Reference: Rework

Approvals: Process Plan: JK Date: _____ Tooling: _____ Date: _____ Run Start *NR1*
 QC: _____ Date: _____ SPC (Y/N): _____ Date: _____ Stop *NR2*

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr	Revision Nbr
IIN D407-781	A

100	Document Control	0.00							
100									
DC	Memo	0.00							
Doc.Control -USB or Paperwork	Photocopy bluefile & type labels per PPP D206-781-023 CHG 001								

110	Pick Kit	0.00							
110									
Packaging	Memo	0.00							
Packaging	PULL FROM STK: 4 X D206-781-023 B98215 1 X D206-781-023 B99927 CHANGE LABEL TO D206-781-023L08 USING NEW B/N PER ECN14-576								

Completed 11/7/14
 [Signature]

115 - QC 21 - 14/11/10 [Signature]
 Close w/o

will 11-06

Linda Lacelle

To: Tad Kling
Subject: RE: D206-781-023

Thx Tad!

From: Tad Kling
Sent: November-07-14 11:47 AM
To: Linda Lacelle
Subject: RE: D206-781-023

SEE ATTACHED
TAD

From: Linda Lacelle
Sent: Thursday, November 06, 2014 11:34 AM
To: Tad Kling; Melissa Thibodeaux
Subject: D206-781-023

Good morning,

I will be sending you some new labels for the 5 kits of D206-781-023's you have in stk. All you have to do is sign off the w/o, and attach the white labels to the outside of each box. The 2 different batches, will now be all the new batch number.

Thx

Linda Lacelle
Production manager
Dart Aerospace